

HOW TO CHANGE YOUR EMBOSSEING WHEEL

IN SECONDS—



1

a. If Tapewriter comes equipped with a wheel screw, remove the screw with a screwdriver.

b. If Tapewriter comes equipped with a Quick-Change Pin, simply pull the Change Pin out.

3

Slip new wheel into housing and align holes. (Slight pressure and centering a letter in window makes alignment easy.)

2

Carefully slip wheel out of housing and place in folder or case to protect the die.

4

Now push the new Quick-Change Pin firmly into the housing. The Change Pin is designed for rapid interchanging of all your DYMO wheels . . . pull the Change Pin out. Slip wheel out/in. Push pin in to lock.



DYMO INDUSTRIES, INC.
P.O. Box 1030, Berkeley 1, Calif.